

SONAI[®]

Super Air Fryer

SH-411




5.5 L

Instruction Manual



www.sonaiworld.com



1	Temperature control knob (80-200°C)	7	Power indicator
2	<ul style="list-style-type: none"> • Switch ON/OFF • Timer knob (0-30 min) 	8	Pan
3	Heating indicator	9	Air outlet openings
4	Pan release button	10	Main cord
5	Basket handle	11	Cooking basket
6	Air inlet openings		

Save These Instructions

While using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should be followed, including the following:

- Read all instructions carefully, even if you are familiar with the appliance.
- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, cord set or plug in water or other liquids.
- To clean, wipe the exterior with a damp cloth.
- Close supervision is necessary when any appliance is used near children.
- Never leave an appliance unattended when in use.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Switch off and remove the plug from the power outlet when not in use, before assembling or disassembling parts, cleaning or carrying out any maintenance of the appliance. Never pull the cord while unplugging out from power outlet.
- Do not operate the appliance if it is damaged in any manner. Return the complete appliance to your nearest authorized service facility for examination, electrical repair, mechanical repair or adjustments to avoid any hazard.
- The use of attachments or accessories not recommended or sold by Sonai may result in fire, electric shock or personal injury.
- Do not let the cord hang over the edge of a table, counter, or touch hot surfaces.
- Avoid touching hot surfaces, use handles and knobs.
- Do not operate or place any part of this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from the outlet; instead, grasp the plug and pull to disconnect.
- When using an extension cord with your appliance, make sure the extension cord is correctly wired, and rated for its use.
- This product is intended for household use only.
- Do not attempt to repair the appliance yourself; instead, take it to your Authorized Service Centre for repair.
- Always leave sufficient space around the appliance for ventilation.
- Do not use the unit if you have wet hands or bare feet.
- Switch off the appliance before changing accessories or approaching parts which move in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children must be supervised to ensure that they do not play with the appliance.
- Take care that the air fryer is connected to a separate circuit, without consumption of other powerful energy consumers such as electric water kettles and the like, because of its high performance. Do not use an extension cord for operating the deep fryer to avoid tripping hazards.
- Do not place anything on top of the air fryer.
- Do not cover the air inlets and air outlets when the air fryer is working.
- Never use the air fryer without the basket / pan in place.
- Keep all ingredients in the basket / pan to prevent any contact with the air fryer's heating elements. Do not overfill the basket.
- During hot air frying, hot steam is released. Keep your hands and face at a safe distance from the steam and from the air outlets. When removing the pan from the air fryer after hot air frying, hot steam will escape, be careful!
- Do not touch the inside of the hot air fryer during or immediately after use, it will be very hot. Always hold by the handle and use oven mitts.

Before First Use

- Place the appliance on a stable, flat and heat-resistant surface.
- Remove all packaging material.
- Remove any stickers or labels from the appliance.
- Thoroughly clean the basket and pan with hot water, some washing-up liquid and non-abrasive sponge.
- Wipe the appliance from inside and outside with a clean damp cloth.

Caution: This is an air fryer that works on hot air.

- Do not fill the cooking basket with oil or frying fat or any other liquid.
- Do not put anything on top of the air fryer.
- Do not put anything near the air vent or on the back of the air fryer.

How To Use Your Super Air Fryer From Sonai

1. Place the air fryer on a stable, flat and heat-resistant surface.
2. Connect the main plug into an earthed wall socket.
3. Carefully pull the pan out of the super air fryer
4. Place the ingredients in the basket.
5. Slide the pan back into the AIR FRYER

Cautions

- Never use the pan without the basket in it.
- Do not touch the pan during and in short-time after use, as it gets very hot. Only hold the pan by the handle.

- 6- Turn the temperature control knob to the requested temperature. (See the cooking table in page 8 to determine the right temperature).
7. To switch on the air fryer, turn the timer knob to the required preparation time.

Add 3 minutes to preparation time if the air fryer is cold.

Note: If you want, you can also preheat the air fryer without any ingredients inside.

- In that case, turn the timer knob for more than 3 minutes and wait until the heating-up light goes out (after about 3 minutes). Then fill the basket and turn the timer knob to the required preparation time.
 - * The power-on light and the heating-up light go on.
 - * The timer starts counting down the requested preparation time.
 - * During the hot air frying process, the heating-up light comes ON and goes OFF from time to time. This indicates that the heating element is switched on and off to maintain the requested temperature.
 - * Excess oil from the ingredients is collected on the bottom of the pan.
- 8- Some ingredients require shaking halfway during the preparation time (see the cooking table in page 8). By this way, pull the pan out of the air fryer by the handle and shake it. Then slide the pan back into the sonai super fryer.

Caution: Do not press the button of the handle during shaking

- 9- When you hear the timer beeps, the set preparation time has elapsed. Pull the pan out of the air fryer and place it on the heat-resistant holder.

Note: You can also switch off the air fryer manually by turning the temperature control knob to (0).

- 10- Check if the ingredients are ready.

Note: if the ingredients are not ready yet, simply slide the pan back into the air fryer and set the timer to a few extra minutes.

- 11- To remove small ingredients (e.g. fries), press the basket release button (4) and lift the basket out of the pan.

Notes

- Don't turn over the pan, otherwise, the oil collected on the bottom of the pan will leak onto the ingredients.
- The pan and the ingredients are hot after hot air frying. Depending on the type of the ingredients in the air fryer, steam may escape from the pan.

- 12- Empty the basket into a bowl or onto a plate.

Tip: To remove large or fragile ingredients, lift the ingredients out of the basket by a pair of tongs.

13- When a batch of ingredients is ready, the super air fryer is instantly ready for preparing another batch.

Settings

- Keep in mind that these settings are indications. As ingredients differ in origin, size, shape and brand, we cannot guarantee the best setting for your ingredients.
- Because the Rapid Air technology reheats the air inside the air fryer instantly, pull the pan briefly out of the air fryer during hot air frying barely disturbs the process.

Air Frying Tips

- A larger amount of ingredients only requires a slightly longer preparation time, a smaller amount of ingredients only requires a slightly shorter preparation time.
- Shaking smaller ingredients halfway during the preparation time optimizes the end result and can help prevent unevenly fried ingredients.
- Add some oil (1/2tbsp) to fresh potatoes for a crispy result. Fry your ingredients in the air fryer within a few minutes after adding the oil.
- Do not prepare extremely greasy ingredients such as sausages in the air fryer
- Snacks can be prepared in an oven can also be prepared in the air fryer.
- The optimal amount for prepare crispy fries is 500 grams.
- Use pre-made dough to prepare filled snacks quickly and easily. Pre-made dough also requires a shorter preparation time than home-made dough.
- Place a baking tin or oven dish in the air fryer basket if you want to bake a cake or quiche or if you want to fry fragile ingredients or filled ingredients.
- You can also use the air fryer to reheat ingredients. To reheat ingredients, set the temperature to 150°C for up to 10 minutes.

Making Home-Made Fries

To make home-made fries, follow the steps below:

- 1- Peel and cut the potatoes (if required)
- 2- Wash the potato sticks thoroughly and dry them with kitchen paper.
- 3- Pour 1/2 tbs of olive oil in a bowl, put the sticks on top and mix until the sticks are coated with oil.
- 4- Put the potato sticks in the basket.

Note: Do not tilt the bowl to pour all the potatoes in the basket at once to prevent excess oil from going into the bottom of the basket.

- 5- Fry the potato sticks according to the fry instructions in the cooking table.

Cooking Tabe: This table below will help you to select the basic settings for the ingrediants.

Food	Min-max Amount (g)	Time (Min)	Temp-erature (°C)	Shake	Extra information
Thick frozen fries	450-1000	20-30	200	✓	
Home-made fries					
(8×8mm)	450-1200	16-22	200	✓	Add 1/2 tbsp of oil
Home-made potato wedges	450-1200	22-26	180	✓	Add 1/2 tbsp of oil
Home-made potato cubes	450-1100	18-24	180	✓	Add 1/2 tbsp of oil
Rosti	350	18-21	180	✓	
Potato gratin	750	18-21	200	✓	
Meat & Poultry					
Steak	150-750	12-16	180		
Hamburger	150-750	14-21	180		
Sausage roll	150-750	15-17	200		
Drumsticks	150-750	22-26	180		
Chicken breast	150-750	15-20	180		
Snacks					
Spring rolls	150-600	10-12	200	✓	
Frozen chicken nuggets	150-750	10-14	200	✓	
Frozen fish fingers	150-600	10-14	200		
Frozen bread crumbed					
Cheese snacks	150-600	10-12	180		
Stuffed vegetables Baking	150-600	20	160		
Cake	450	25-30	160		Use baking tin
Quiche	600	22-24	180		Use baking tin/oven dish
Muffins	450	18-21	200		Use baking tin
Sweet snacks	600	30	160		Use baking tin/oven dish

Troubleshooting

Problem	Possible cause	Solution
The air fryer does not work	The appliance is not plugged in	Connect the plug to an earthed wall socket.
	You have not set the timer	Turn the timer knob to the required time to switch on the air fryer.
The ingredients fried in the air fryer are not evenly fried	The amount of ingredients in the basket are too big.	Out smaller batches of ingredients in the basket. Smaller batches are fried more evenly.
	The set temperature is too low.	Turn the temperature control knob to the required Temperature setting. (See the cooking table in page 8).
The ingredients are fried unevenly in the air fryer	Certain types of ingredients need to be shaken halfway through the preparation time	Ingredients that lie on top of or across each other (e.g. fries) need to be shaken halfway through the preparation time. (See the cooking table in page 8).
Fried snacks are not crispy	You used a type of snacks meant to be prepared in a traditional deep fryer.	Use oven snacks or lightly brush some oil onto the snacks for a crispier result.
I cannot slide the pan into the air fryer properly	There are too much ingredients in the basket.	Do not fill the basket beyond the MAX indication.
	The basket is not placed in the pan correctly.	Push the basket down into the pan until you hear a click.
Smoke comes out from the air fryer.	You are preparing greasy ingredients.	When you fry greasy ingredients in the air fryer, a large amount of oil will leak into the pan. The oil produces smoke and the pan may heat up more than usual. This does not affect the appliance or the end result.
	The pan still contains grease residues from previous use	Smoke is caused by grease heating up in the pan. Make sure you clean the pan properly after each use.
Fresh fries are fried unevenly in the air fryer	You did not use the right potato type.	Use fresh potatoes and make sure that they stay firm during frying.
	You did not rinse the potato sticks properly before you fried them.	Rinse the potato sticks properly to remove starch from the outside of the sticks.
Fresh fries are not crispy when they come out of the air fryer	The crispiness of the fries depends on the amount of oil and water in the fries.	Make sure you dry the potato sticks properly before you add the oil. Cut the potato sticks smaller for a crispier result
		Add slightly more oil for a crispier result.

Cleaning and Maintenance

- Clean the air fryer after every use.
- Do not clean the pan, basket and the inside of the appliance by metal kitchen utensils or abrasive cleaning materials, as this may damage the non-stick coating of them.

1- Remove the plug from the wall socket and leave the appliance to cool down.

Note: Remove the pan to let the air fryer cool down more quickly.

2- Wipe the outside of the air fryer with a moist cloth.

3- Clean the pan and basket with hot water, some washing-up liquid and a non-abrasive sponge.

Note: you can remove any remaining dirt by degreasing liquid.

Tip: If dirt is stuck to the basket or to the bottom of the pan, fill the pan with hot water and some washing-up liquid. Put the basket in the pan and let the pan and the basket soak for about 10 minutes.

4- Clean the inside of the air fryer with damp hot water cloth and non-abrasive sponge.

5- Clean the heating element with a cleaning brush to remove any food residues. **(Do not use any kind of detergents).**

Note: Fry pan basket are dishwasher safe.

Storage

1- Unplug the appliance.

2- Make sure all parts are clean and dry.

3- Make sure that the basket and the pan are in the right position.

4- Store your appliance in a dry/clean closet and keep it away from the reach of children.

Electrical Safety



Always check that the power supply corresponds to the voltage on the rating plate.

To avoid the risk of electric shock, do not immerse the cord, plug or motor unit in water or other liquid.

Protecting the environment



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

التنظيف والصيانة

- قم بتنظيف الجهاز بعد كل إستخدام.
- لا تقم بتنظيف الحلة الداخلية والسلة والجهاز من الداخل بإستخدام أدوات مطبخ معدنية أو أدوات تنظيف كاشطة؛ لأن ذلك قد يؤدي إلى تلف الطبقة التي تعمل على عدم التصاق الطعام.
- 1- قم بإزالة القابس الأساسي من مقبس الحائط واطرك الجهاز ليبرد.
- ملاحظة:** قم بإزالة الحلة الداخلية حتى تبرد المقلاة الهوائية أسرع.
- 2- قم بمسح الجهاز من الخارج بقطعة قماش مبللة.
- 3- قم بتنظيف الحلة الداخلية والسلة بالماء الساخن والقليل من سائل غسل الصحون واسفنجة غير كاشطة (ناعمة).
- ملاحظة:** يمكنك إزالة الأوساخ المتبقية بإستخدام سائل إزالة الدهون.
- نصيحة:** إذا التصقت الأوساخ في السلة أو قاع الحلة الداخلية، املا الحلة الداخلية بالماء الساخن مع القليل من سائل غسل الصحون. ضع السلة في الحلة الداخلية واطركها منقوعان لمدة تصل إلى 10 دقائق.
- 4- قم بغسل الجهاز من الداخل بقطعة قماش مبللة بماء ساخن واسفنجة غير كاشطة.
- 5- قم بتنظيف الأجزاء المسنولة عن التسخين بإستخدام فرشاة التنظيف لإزالة بقايا الطعام (لا تستخدم الصابون).
- ملاحظة:** يمكن تنظيف الحلة الداخلية و سلة المقلاة في غسالة الأطباق.

التخزين

- 1- قم بفصل الجهاز
- 2- تأكد من نظافة جميع الأجزاء وجفافها.
- 3- تأكد من وجود السلة / الحلة في المكان المخصص.
- 4- يمكنك الآن تخزين الجهاز في مكان جاف وبعيد عن متناول الأطفال.

السلامة الكهربائية

التأكد من توافق محول الكهرباء مع الجهد الكهربائي للجهاز في لوحة البيان.
تجنب غمر السلك أو القابس في أي سوائل لتجنب خطر الصدمة الكهربائية.



حماية البيئة

تشير هذه العلامة إلى ضرورة عدم التخلص من المنتج بعد تلفه بالطرق العادية للتخلص من النفايات المنزلية في دول الإتحاد الأوروبي، لمنع حدوث أي أضرار محتملة تؤثر سلبا على البيئة أو صحة الإنسان نتيجة لإتباع طرق التخلص من المخلفات بصورة غير منضبطة أو إعادة تدويرها بشكل يسمح بإعادة إستخدامها بصورة مستمرة. لكي يتسنى لك إعادة المنتج بعد إستخدامه، يرجى إتباع أنظمة الإعادة والتجميع أو الإتصال بتاجر التجزئة الذي اشتريت منه المنتج حيث يمكنه تدويره بطريقة آمنة على البيئة.



الحل	سبب حدوثها	نوع المشكلة
قم بتوصيل القابس الأساسي بمقبس الكهرباء في الحائط	الجهاز غير موصل بالمقبس	المقلاة الهوائية لا تعمل
قم بإدارة مفتاح المؤقت لضبطه على الوقت المطلوب لتشغيل الجهاز.	لم يتم ضبط المؤقت	
ضع كمية الطعام على دفعات أقل في السلة، لأن الكميات الأقل من الطعام يتم قليها بطريقة متساوية أكثر.	كمية الطعام الموجودة في السلة كبيرة عن سعتها.	الطعام المقلي في المقلاة الهوائية غير مطهي بشكل جيد.
قم بإدارة مفتاح التحكم في درجات الحرارة إلى درجة الحرارة المطلوبة (انظر الى جدول الطهي صفحة ١٤)	درجة الحرارة التي تم ضبطها منخفضة جدًا.	
يحتاج الطعام المتكدس أو الملتصق ببعضه(مثل البطاطس المقلية) إلى التحريك أثناء عملية الطهي. انظر الى جدول الطهي صفحة ١٤	يحتاج بعض أنواع الطعام إلى التحريك أثناء عملية الطهي.	لم يتم قلي الطعام بطريقة متساوية في المقلاة الهوائية
استخدم الوجبات الخفيفة التي يتم تحضيرها في الفرن أو ادهن هذه الوجبات الخفيفة بالزيت لتصبح مقرمشة.	استخدمت نوع من الوجبات الخفيفة يتعين تحضيرها في مقلاة تقليدية	لم تكن الوجبات الخفيفة المقلية مقرمشة عند إخراجها من المقلاة الهوائية
لا تملأ السلة بكمية تتجاوز مؤشر الحد الأقصى.	وضعت كمية كبيرة من الطعام في السلة.	لا يمكنني إدخال الحلة الداخلية في الجهاز بطريقة صحيحة.
ادفع السلة إلى أسفل الحلة الداخلية حتى تسمع صوت طقطقة.	لم يتم وضع السلة في الحلة الداخلية بطريقة صحيحة.	
عند قلي طعام به دهون في المقلاة الهوائية ستسرب كمية كبيرة من الدهون إلى الحلة الداخلية. وستسبب الدهون في تصاعد دخان وقد تزداد سخونة الحلة الداخلية أكثر من العادة. وهذا لا يؤثر على الجهاز أو على النتيجة النهائية.	تقوم بإعداد طعام به دهون.	تصاعد دخان من الجهاز.
تتسبب الدهون التي يتم تسخينها في الحلة الداخلية في تصاعد دخان أبيض. تأكد من تنظيف الحلة الداخلية بشكل صحيح بعد كل استخدام.	لا تزال الحلة الداخلية تحتوي على بقايا دهنية من الاستخدام السابق	
استخدم بطاطس طازجة واحرص على أن تبقى سليمة أثناء قليها.	لم تستخدم نوع البطاطس المناسب.	لم يتم قلي البطاطس المقلية بطريقة متساوية في المقلاة الهوائية.
قم بغسل أصابع البطاطس جيدًا لإزالة النشا منها.	لم تغسل أصابع البطاطس جيدًا قبل قليها.	
تأكد من تجفيف شرائح البطاطس جيدًا قبل إضافة الزيت. قم بتقطيع أصابع البطاطس إلى قطع أصغر لتصبح مقرمشة أكثر.	تكون البطاطس مقرمشة حسب كمية الزيت والمياه الموجودة فيها.	لم تكن البطاطس الطازجة مقرمشة عند إخراجها من المقلاة الهوائية
قم بإضافة القليل من الزيت للحصول على نتائج أكثر قرمشة.		

جدول الطهي: سيساعدك الجدول بأسفل على اختيار الإعدادات الأساسية الطعام.

معلومات إضافية	تحريك	درجة الحرارة (°C)	الوقت (دقائق)	أقل-أكبر كمية (جرام)	نوع الطعام
	✓	200	20-30	450-1000	بطاطس مقليه مقطعة لشرائح سميكة
بطاطس معدة بالمنزل					
إضافة ½ ملعقة طعام من الزيت	✓	200	16-22	450-1200	(8×8 مم)
إضافة ½ ملعقة طعام من الزيت	✓	180	22-26	450-1200	قطع بطاطس (ودجز)
إضافة ½ ملعقة طعام من الزيت	✓	180	18-24	450-1100	مكعبات بطاطس
	✓	180	18-21	350	بطاطس روسي
	✓	200	18-21	750	غراتان البطاطا
لحوم ودواجن					
		180	12-16	150-750	شريحة لحم
		180	14-21	150-750	هامبرغر
		200	15-17	150-750	لحافن نقائق
		180	22-26	150-750	دبابيس دجاج
		180	15-20	150-750	صدر دجاج
الوجبات الخفيفة					
	✓	200	10-12	150-600	لحافن الربيع (سبرنج رول)
	✓	200	10-14	150-750	قطع دجاج صغيرة (ناجتس) مقليه مجمدة
		200	10-14	150-600	أصابع سمك مجمد
الخبز المجمد					
		180	10-12	150-600	وجبات الجبن الخفيفة
		160	20	150-600	مخبوزات محشية
استخدم صينية للخبز		160	25-30	450	كيك
استخدم صينية للخبز		180	22-24	600	فطائر الكيش
استخدم صينية للخبز		200	18-21	450	فطائر وكعك المافن
استخدم صينية للخبز		160	30	600	وجبات خفيفة من الحلوى

الإعدادات

- تذكر أن هذه الإعدادات هي لنوعى الإستعمال. ونظرًا لأن الطعام يختلف من حيث المصدر والحجم والشكل والعلامة التجارية، فلا يمكننا ضمان أفضل إعداد لطعامك.
- نظرًا لأن تقنية الهواء السريع الساخن «Rapid Hot Air» تعمل على إعادة تسخين الهواء داخل الجهاز على الفور، فإن إخراج الحلة الداخلية من الجهاز أثناء الإستخدام لوقت قصير لن يؤثر على عملية الطهي.

نصائح متعلقة بالمقلاة الهوائية

- تتطلب الكميات الكبيرة من الطعام وقت أطول للتحمير، بينما تتطلب الكميات القليلة من الطعام وقت أقل للتحمير.
- تحريك الكميات القليلة من الطعام أثناء وقت التحمير يؤدي إلى نتيجة أفضل ويساعد على تسوية الطعام بالكامل بشكل متساوٍ.
- قم بإضافة ½ ملعقة زيت كبيرة للبطاطس الطازجة للحصول على بطاطس مقالية مقرمشة. قم بوضع الطعام في المقلاة الهوائية بعد دقائق قليلة من وضع الزيت.
- لا تقم بإعداد الطعام المليء بالدهون مثل النقانق في المقلاة الهوائية.
- الوجبات الخفيفة التي يمكن إعدادها في فرن يمكن أيضًا إعدادها في المقلاة الهوائية.
- الكمية المناسبة لإعداد البطاطس المقالية المقرمشة هي 500 جرام.
- قم بإستخدام العجينة الجاهزة لإعداد الوجبات الخفيفة المحشوة بسرعة وسهولة. كما تتطلب العجينة الجاهزة وقت تحمير أقل من العجينة المعدة في المنزل.
- قم بوضع صينية للخبز أو طبق مخصص لدخول الفرن في سلة المقلاة الهوائية إذا كنت ترغب في خبز كعكة أو كيش، أو إذا كنت ترغب في قلي الطعام الهش أو المحشو.
- يمكنك أيضًا إستخدام المقلاة الهوائية لإعادة تسخين الطعام. وللقيام بذلك، اضبط درجة الحرارة على 150 درجة مئوية لمدة تصل إلى 10 دقائق.

صنع البطاطس المعدة في المنزل

لصنع البطاطس المقالية المعدة في المنزل اتبع الخطوات التالية.

- 1- قم بتقشير البطاطس وقطعها الى صابع.
 - 2- قم بغسل أصابع البطاطس جيدًا وجففها باستخدام ورق المطبخ.
 - 3- ضع ½ ملعقة من زيت الزيتون في وعاء، ثم ضع البطاطس وقلّبها حتى تغطى البطاطس بالزيت.
 - 4- قم بإزالة البطاطس من الوعاء بإستخدام أدوات المطبخ بحيث يبقى الزيت الزائد في الوعاء ثم ضعها في السلة.
- ملاحظة:** لا تقم بإمالة الوعاء لوضع جميع البطاطس في السلة دفعة واحدة لتجنب وصول الزيت الزائد إلى قاع الحلة الداخلية.
- 5- قم بقلي أصابع البطاطس وفقًا لجدول الطهي.

6- ادر مقبض التحكم فى درجة الحرارة الى درجة الحرارة المطلوبة (انظر الى جدول الطهى فى صفحة 13).

7- لتشغيل الجهاز، قم بإدارة مفتاح المؤقت لضبطه على وقت تحضير الطعام المطلوب.
قم بإضافة ٣ دقائق أخرى إلى وقت التحضير في حالة كان الجهاز بارداً.

ملاحظة: يمكنك تسخين الجهاز مسبقاً دون وجود طعام بداخله إن رغبت في ذلك. فقط اضبط مفتاح المؤقت على ٣ دقائق وانتظر حتى ينطفئ ضوء التسخين بعدها قم بوضع الطعام داخل السلة واعدّها إلى مكانها الصحيح داخل المقلاة الهوائية.

* يضى ضوء التشغيل وضوء التسخين.

* سيبدأ المؤقت بالعد التنازلي وفقاً لوقت التحضير الذي تم ضبطه.

* أثناء عملية القلي بالهواء الساخن ينير ضوء التسخين وينطفئ من حين لآخر، وهذا يعني أن خاصية التسخين تعمل وتتطفئ للحفاظ على درجة الحرارة التي تم ضبطها مسبقاً.

* يتم جمع الزيت الزائد من الطعام في قاع الحلة الداخلية.

8- تتطلب بعض أنواع الطعام أن يتم تحريكها في منتصف وقت التحضير (انظر الى جدول الطهى فى صفحة 13)، ولفعل هذا قم بسحب الحلة الداخلية خارج الجهاز عن طريق المقبض وحركها، ثم أدخل الحلة مرة أخرى إلى المقلاة.

تحذير: لا تضغط على زر المقبض أثناء التحريك.

9 عند سماع جرس المؤقت، فإن هذا يعني أن وقت التحضير الذي تم ضبطه قد انتهى. قم بعد ذلك بسحب الحلة الداخلية خارج الجهاز وضعها على سطح مقاوم للحرارة.

ملاحظة: يمكنك إغلاق الجهاز يدوياً عن طريق إدارة مفتاح التحكم في درجة الحرارة إلى درجة (0).
10- قم بالتأكد من أن الطعام أصبح جاهزاً.

ملاحظة: إذا لم يصبح جاهزاً بعد، فيكل بساطة أدخل الحلة الداخلية مرة أخرى داخل الجهاز واضبط المؤقت على بضع دقائق إضافية.

11- لإزالة المكونات الصغيرة (مثل البطاطس المقلية) اضغط على زر إزالة السلة (4) وارفع السلة للخارج.

ملاحظات

• لا تقم بقلب الحلة الداخلية، وإلا سيتسرب الزيت المتجمع في قاع الحلة الداخلية إلى الطعام.
• تكون الحلة الداخلية والطعام الموجود بداخلها ساخنين بعد القلي. وقد يخرج البخار من الحلة الداخلية حسب نوع الطعام الموجود في المقلاة الهوائية.

12- قم بتفريغ السلة في وعاء أو طبق.

نصيحة: لتفريغ محتويات الحلة، قم بإخراج الطعام من السلة بملقاط الطعام أو الأدوات المعدة لذلك.
13- عندما تكون وجبة من الطعام جاهزة، تكون المقلاة السحرية جاهزة لإعداد وجبة طعام أخرى على الفور.

- لأن هذه المقلاة تتطلب جهداً كهربائياً عالياً، احرص على توصيلها بدائرة كهربائية منفصلة، بعيدة عن أي مصادر أخرى مستهلكة للطاقة مثل غلايات المياه الكهربائية وما شابه ذلك و في حالة استخدام سلك تمديد، يرجى التأكد من توصيله بشكل سليم وأنه صالح للإستخدام مع هذا الجهاز.
- لا تقم بوضع أي شيء فوق الجهاز.
- لا تقم بتغطية فتحات دخول وخروج الهواء أثناء تشغيل الجهاز.
- لا تستخدم المقلاة الهوائية مطلقاً دون وضع الحلة الداخلية في مكانها الصحيح.
- قم بإبقاء جميع مكونات الطعام في سلة الطهي لمنع أي تلامس مع عناصر تسخين الجهاز. ولا تملأ السلة أكثر من اللازم.
- أثناء القلي بالهواء الساخن، يخرج بخار ساخن. لذا ابعد يديك ووجهك مسافة كافية عن البخار وفتحات خروج الهواء. بعد إزالة الحلة الداخلية من الجهاز سيخرج بخار القلي الساخن، فاحترس.
- لا تقم بلمس المقلاة الهوائية من الداخل أثناء الإستخدام أو بعده مباشرة لأنها ستكون ساخنة للغاية. وامسكها دائماً من مقبضها فقط، وإستخدم دائماً قفازات الفرن.

قبل الإستخدام لأول مرة

- ضع الجهاز على سطح ثابت مقاوم للحرارة.
- قم بإزالة جميع مواد التغليف.
- قم بإزالة أي ملصقات أو علامات موجودة على الجهاز.
- قم بتنظيف سلة الطعام و الحلة الداخلية بالماء الساخن بإستخدام القليل من سائل غسل الصحون و اسفنج ناعمة.
- قم بمسح الجهاز من الداخل و الخارج بقطعة قماش رطبة.

تحذير: تعمل هذه المقلاة الهوائية بالهواء الساخن

- لا تملأ السلة بالزيت أو بدهون قلي أو بأى سوائل أخرى.
- لا تقم بوضع أي شيء فوق الجهاز، لكي لا يختل تدفق الهواء.
- لا تقم بوضع أي شيء بالقرب من فتحة التهوية.

كيفية إستخدام المقلاة الهوائية سوبر من سوناي

- 1- قم بوضع الجهاز على سطح ثابت و مقاوم للحرارة.
- 2- قم بتوصيل المقلاة بمقبس الكهرباء في الحائط.
- 3- قم بسحب الحلة الداخلية بحرص خارج المقلاة.
- 4- ضع مكونات الطعام داخل السلة.
- 5- أعد الحلة الداخلية إلى المقلاة الهوائية.


تحذير

- لا تستخدم الحلة الداخلية مطلقاً من دون السلة الموجودة فيها.
- لا تلمس الحلة الداخلية أثناء الإستخدام وبعد وقت قصير من الإستخدام لأنها ستكون ساخنة للغاية، وأمسك الحلة الداخلية من مقبضها فقط.

إرشادات هامة

هناك إحتياطات سلامة يجب إتباعها أثناء إستخدام الأجهزة الكهربائية للتقليل من خطر الحريق والصدمة الكهربائية أو إصابة الأشخاص وتشمل هذه الإحتياطات ما يلي:

- قراءة كل هذه التعليمات بعناية حتى ولو كنت على دراية بإستخدام الجهاز.
- لا تغمر الجهاز أو مجموعة الأسلاك أو القابس فى الماء أو السوائل الأخرى حتى لا تتعرض لصدمة كهربائية.
- إستخدم قطعة قماش مبللة لتنظيف ومسح الجزء الخارجى من الجهاز.
- راقب الأطفال عن كثب عند إستخدام الجهاز بالقرب منهم. لا تترك الجهاز دون مراقبة أثناء إستخدامه.
- فى حالة تلف سلك الطاقة، يرجى الإستعانة بمصنع الجهاز أو وكيل الخدمة المعتمدة أو أى فنى على نفس درجة التأهيل لإستبدال السلك التالف وذلك لتجنب أى مخاطر ممكنة.
- قم بفصل الجهاز وانزع القابس من مأخذ التيار الكهربائى أثناء عدم الإستخدام أو قبل تركيب أو فك أجزائه أو تنظيف أو إجراء صيانة للجهاز. لا تشد السلك لنزع القابس من مأخذ التيار الكهربائى.
- لا تشغل الجهاز بسلك أو قابس تالف، يجب الإستعانة بمركز الخدمة المعتمدة لمعاينة الجهاز أو إصلاحه كهربائياً أو ميكانيكياً لتجنب أى خطر.
- قد تترتب مخاطر الحريق أو الصدمة الكهربائية أو إصابة الأفراد عند إستخدام الملحقات الثانوية التى لم توصى بها سوناي أو تقوم ببيعها.
- لا تدع السلك يندلى فوق حافة المنضدة أو يلامس أسطحاً ساخنة.
- تجنب ملامسة الأسطح الساخنة مع مراعاة إستخدام المقابض.
- لا تضع الجهاز أو أى جزء من أجزائه على أسطح ساخنة (مثل فرن غاز أو فرن كهربائى ساخن أو فى فرن تم إحماؤه) أو بالقرب منها.
- لا تسيء إستخدام السلك ولا تحمل الجهاز أبداً عن طريق السلك أو شده لفصله من مأخذ التيار اقبض على القابس دائماً واسحبه لفصله.
- فى حالة إستخدام سلك تمديد، يرجى التأكد من توصيله بشكل سليم وأنه صالح للإستخدام مع هذا الجهاز.
- هذا الجهاز معد للإستخدام المنزلى فقط.
- لا تحاول إصلاح الجهاز بنفسك، ولكن استعن بأقرب مركز خدمة تابع أو معتمد لإصلاح الجهاز.
- احرص دائماً على ترك مساحة كافية حول الجهاز للتهوية.
- لا تستخدم الوحدة إذا كانت يداك مبتلتين أو قدمك عاريتين.
- افصل التيار الكهربائى عن الجهاز قبل تغيير الأدوات الملحقة أو الإقتراب من الأجزاء التى تتحرك أثناء الإستخدام.
- هذا الجهاز غير معد لإستخدامه من جانب أشخاص (بمن فى ذلك الأطفال) لديهم قدرات جسدية وحسية وعقلية منخفضة، أو تنقصهم الخبرة والمعرفة، مالم يكونوا قد حصلوا على إشراف أو تعليمات بشأن إستخدام الجهاز من جانب شخص مسئول عن سلامتهم.
- يجب مراقبة الأطفال والإشراف عليهم للتأكد من عدم عبثهم بالجهاز.



مؤشر التشغيل	7	مفتاح التحكم بدرجات الحرارة (200-80 درجة مئوية)	1
الحلة	8	• مفتاح التشغيل • مفتاح المؤقت (30-0 دقيقة)	2
فتحات مخرج الهواء	9	مؤشر الحرارة	3
المالك الرئيسي	10	زر إزالة الحلة	4
سلة الطهي	11	مقبض الحلة	5
		فتحات مدخل الهواء	6

SONAI®

مقلاة هوائية "سوبر"

SH-411



5.5 L

تعليمات التشغيل



www.sonaiworld.com